

UNIT EXCHANGE



These components come fully assembled, tested and ready to install. This system allows our customers to minimize their equipment down time. Installation services are also available on all unit exchanges.

After installation of the new unit, simply return your old unit for a core credit.

Exchanges include:

- mechanical swing shaft
- boom hoist shaft
- main hoist shaft
- main clutch shaft
- engine and generator
- traction motors, truck assemblies
- drive and idler axles
- compressors
- plus many more



IPS houses an extensive inventory of components for American and Ohio Locomotive Cranes.